
**NE 4680-T** 

Swing-A-Slide)

# We Put Kids First. TWISTER TUDE Slide

check out http://www.swing-n-slide.com for updates to these instructions.



## **ASSEMBLY INSTRUCTIONS**

Swing•N•Slide • 1212 Barberry Drive • Janesville, Wisconsin 53545 Visit our web site at: www.swing-n-slide.com or call us at 1-800-888-1232



## Safety Checklist for Swing-N-Slide Play Sets and Accessories

Observing the following statements and warnings reduces the likelihood of serious or fatal injury

Installa	ition Safety – Have You:
	Consulted the assembly instructions supplied with your particular model?
	Noted this accessory is to be used only on Swing•N•Slide approved designs? (Do not alter its design or add/remove components.)
	Made sure all hardware is tightened securely? (Supplied bolt covers must also be fastened securely.)
	Using a hacksaw, cut off all protruding threaded ends of bolts and other fasteners and remove any sharp edges with
	a metal file as needed?
	Placed the equipment on level ground, not less than six feet (1.8 meters) from any structure or obstruction such as a fence, garage,
	house, overhanging branches, laundry lines, or electrical wires?
	Made sure home playground equipment is not installed over concrete, asphalt, packed earth or any other hard surface? (A fall onto
	a hard surface can result in serious injury to the equipment user.)
	Verified that suspended climbing ropes, chain, or cable are secured at both ends?
	Consulted in assembly instructions of your particular model for minimum use zones?
	Followed all anchoring and shock absorbing surfacing requirements on the back of this sheet as they apply?
	Made sure not to allow children to use equipment until it is properly installed?
Operat	t <b>ing Safety</b> – Have You:
	Determined that on-site adult supervision is provided for children of all ages?
	Warned children the following before allowing them to use the equipment?
	□ Not to walk close to, in front of, behind or between moving items.
	Not to twist swing or any other accessory chains or ropes or loop them over the top support bar since this will reduce the
	strength of chain or rope.
	□ Not to swing empty seats or other accessories.
	Be sure to sit in the center of the swing seat and other accessories with full weight on the seat.
	Not to attach items to the playground equipment that are not specifically designed for use with the equipment such as but not
	limited to, jump ropes, clotheslines, pet leashes, cables and chain. They may cause a strangulation hazard.
	Not to use equipment in a manner other than intended.
	□ Not to get off equipment while it is in motion.
	Not to climb on the equipment when it is wet.
	Determined that only one child per planned occupant seat should be allowed on this set at one time.
	Determined children must be dressed appropriately for play. Avoid clothing with draw strings and loose fitting clothes which
	could become entangled or snagged on equipment.
	Determined that suspended climbing ropes, chain, or cable cannot be looped back upon itself.
	Read and understood the following warning regarding the use of two and four passenger lawn swings?
	Warning: Lawn Swings are designed for use by children over two years of age. Use by children under the age of two can result
	in entrapment between the seats and back areas. <b>Never</b> place children in a rearward facing position or with legs between the
	seat and backrest because the child's body may pass through the opening causing entrapment of the child's head.
	Maintenance – Have You Determined to:
Ш	Check all nuts and bolts twice monthly during the usage season for tightness and tighten as required? (It is
_	particularly important that this procedure be followed at the beginning of each season.)
	To prevent the deterioration of materials, remove plastic swing seats and other plastic accessories and take indoors? (Do not
_	use when the temperature drops below 0° F.)
	Oil all metallic moving parts monthly during usage period?
	Check all hardware and equipment for sharp edges twice monthly during usage season? (Replace when
_	necessary. It is especially important to do this at the beginning of each new season.)
	Check swing seats, chains, ropes and cables monthly during usage season for evidence of deterioration? Severe rusting or excessive
	wear, especially near the top swing hanger or at the seat connection are evidence of chain deterioration. Cracks in the protective plastic
_	sleeve or seat itself are also signs of deterioration. If any of these conditions exist, call 1-800-888-1232 to order replacement accessories.
	Sand rusted metal parts and repaint using non-lead based paint.

#### **Disposal Instructions**

When the equipment is taken out of service, it must be disassembled and disposed of in such a way that no unreasonable hazards will exist at the time the set is discarded.

This product is intended for single family home/residential use only and not intended for use in any public setting.

Placement in any public setting constitutes a misuse of this product.

#### **IMPORTANT!**

ADDITIONAL REQUIRED SAFETY INSTALLATION INSTRUCTIONS

According to ASTM requirements, all kits must be anchored to the ground and, if the unit has a climbing rope, the rope end must be anchored to the ground. If soil conditions permit stakes to be pulled out easily, cementing into ground is necessary.

- To anchor the unit to the ground, Follow the instructions included in this plan for applying Anchor-It devices to your unit, or use 2" x 4" x 18" (45mm x 95mm x 457mm) pressure-treated stakes. Pound stakes into ground at least 12" (305mm) at all inside corners of the posts (including A-frame legs and climbing unit posts). Attach with four (4) 16D (3-1/2") galvanized nails per stake into each 4" x 4" (95mm x 95mm) post.
- If the unit has a climbing rope, anchor the rope end.
- Once the unit is completely assembled and before children are allowed to play on it, proper shock-absorbing surfacing material must be installed. This may be accomplished by using loose-fill materials at a sufficient depth. The Consumer Product Safety Commission "Handbook for Public Playground Safety" lists the following materials and required depths that are sufficient for home/residential application. For fall height protection up to 9 ft. (2.742m) [recommended for Swing•N•Slide kits]:

#### LOOSE FILL MATERIAL

REQUIRED (UNCOMPRESSED) DEPTH<sup>1</sup> in. (mm)

Wood Mulch Double Shredded Bark Mulch Uniform Wood Chips Fine Sand

9" (229mm) 9" (229mm) 9" (229mm) 12" (305mm) 12" (305mm) 12" (305mm)

Fine Gravel

These depths were derived from the CPSC Handbook. Swing•N•Slide has not done independent tests to determine these required depths.

When properly installed, shock absorbing material will completely cover the horizontal baseboards on climbing units. This protective surfacing must extend a minimum of 6 ft. (1.828m) in all directions from the perimeter of the equipment or from the outermost edges of any component. For example, a slide extending beyond the platform must have protective surfacing at least 6 ft. (1.828mm) out from both sides as well as the end. For swings, the protective surface must extend at least 14 ft. (6m) out from both the back and front of the swing when the swing is in its rest position.

**Notes:** 

## **ASSEMBLY INSTRUCTIONS**

## HARDWARE PURCHASED SEPARATELY

(14) 1-1/4" deck screws

(12) 2" deck screws

(44) 2-1/2" deck screws

## **LUMBER PURCHASED SEPARATELY**

(2)-2" x 4" x 96" (1)-2" x 4" x 120" Note: To match the wood appearance on your playset, make certain to use the precise Wood Stain listed at www.swing-n-slide.com

## **LUMBER CUT LIST**

	47-1/2"				X				
(1) 2" x 4" x 96"									
18"	18"	18"	8	-1/4"	8-1/4"	11-1/2"			
(1) 2" x 4" x 96"									
28"		28"		23-1/4"			23-1/4"	17"	

(1) 2" x 4" x 120"

## TOOLS REQUIRED



**ELECTRIC DRILL** 




**CIRCULAR SAW** 




**TAPE MEASURE** 



1/2" SOCKET & WRENCH



HAMMER



**PHILLIPS BIT** 




**SQUARE** 



SAFETY GLASSES & DUST MASK


## **SLIDE COMPONENTS**



(1) Entrance Panel




(1) Support Bracket




(1) Entrance Section marked no. 1




(1) Entrance Section marked no.2




(1) 90° Sections w/o flange, marked no. 3




(1) Exit Section marked no. 5



(1) Slide Base marked no. 6



(12) 1-1/2" lag bolts



(4) 2-1/2" lag bolts



(45) 3/4" bolts




(4) 1" bolts




(49) loc nuts



(98) 5/16" flat washers






## 2-1/2" screw


#### **B. Slide Barrier Construction**

1. Carefully remove (2) 1" x 4" Barrier Supports and (8) 1" x 4" Barrier Boards from the barrier where you would like to place your slide, making certain you will have a clear 72" Safety Zone for your slide. (Fig. 2).

**Retain** this lumber as you will need it in the following steps.

- **2.** Install (2) 2" x 4" Barrier Support Boards as shown in **(Fig. 2a)**, making certain the opening between them is 28".
- **3.** To fill the gap created above the top 2" x 4" reinstall (1) 1" x 4" x 47-1/2" board as shown in **(Fig. 2a)**.







## 1-1/4" screw

### C. Slide Barrier Cont.

- Install (3) 1" x 4" Barrier Boards as shown in (Fig. 3). Space Barrier boards as shown and make certain your opening is 23-1/4" wide.
- 2. Install (2) 2" x 4" x 28" Boards as shown in (Fig. 3a).
- **3.** Install (2) 2" x 4" x 23-1/4" Slide Support Boards on the inside of your barrier as shown in **(Fig. 3b)**.







### **D. Slide Support and Entry**

Align the mounting panel to the previously assembled entrance section (Fig. 4). Attach the mounting panel to the entrance section at the hole locations indicated in (Fig. 4a) using one 1" bolt, two washers and one loc nut per hole as indicated in (Fig. 4b).


**NOTE:** Hand tighten the loc nuts only.






### **E. SLIDE ASSEMBLY**


- 1. Attach the Run-Off Section to the Exit Section as shown in (Fig. 5) using (6) 3/4" Hex Head Bolts, (12) 5/16" Washers and (6) Loc- Nuts.
- 2. Connect the Exit Section to the Entrance Section as shown in (Fig. 5).
- **3.** Secure the Entrance Section and the Exit Section using (12) 3/4" Hex Head Bolts, (24) 5/16" Washers and (12) Loc Nuts.
- 4. Tighten all hardware completely.



### F. Secure Slide In Place

1. Attach Twister Tube Slide to your prepared entrance as shown in (Fig. 6).






## G. SUPPORT AND BRACKET ASSEMBLY

- 1. Assemble the support base as shown in (FIG. 7).
- Attach the support bracket to the support base using two 1-1/2" lag bolts (FIG. 7a).
   NOTE: Pre-drill 1/8" pilot holes.
- 3. Place the support beneath the slide base and determine its final position. **NOTE:** Slide support should fit tightly beneath the slide to assure proper support. Remove corresponding nut and bolt, attach support to the slide as indicated in **(FIG. 7b)**. Re-attach hardware.
- **4.** Level grade at the bottom of the slide.

Fig. 8



## H. Slide Installation.

- 1. Position slide to determine proper location for stake.
- 2. Drive wood stake into ground leaving 2" exposed.
- **3.** Secure the slide bottom to the stake using (2) 1-1/4" deck screws. (Fig. 8).

Twister Tube Assembly Instructions					

	I wister_I ube_Assembly Instruction.

# Questions???... Call our Customer Service Department at 1-800-888-1232



We Put Kids First.